


HIGHLAND MEDIA NOVA CE 4 DEVICE REMOTE CONTROL USER'S GUIDE



Installing Batteries

- 1 Remove battery cover.
- 2 Insert 2 AA batteries. Match the + and - marks.
- 3 Replace battery cover.

Note: The red LED will blink 5 times with each key press when batteries need replacement.

LED FEEDBACK FOR PROGRAMMING
 2 BLINKS = @SUCCESS
 1 LONG BLINK = @FAILURE

Device Setup

- 1 Press the mode key for the device you wish to set up.
- 2 Press and hold SET until the red LED blinks twice.
- 3 Enter the 1st code for your brand from the code list.
- 4 Press power key to test with your equipment. If the device turns off, setup is complete.
- 5 If device does not turn off, then repeat SETUP using the next code for your brand.

Code Search

- 1 Press the mode key for the device you wish to set up.
- 2 Press and hold SET until the red LED blinks twice.
- 3 Enter in 9-9-1, then the device group number.

 0 Cable Converters, Video Accessories, Satellite Receivers
 1 TV (TVs)
 2 VCR (VCRs, DVD players)
 3 Audio (Audio Amplifiers, Audio Amp/Tuners, CD players)
- 4 Aim the remote the device and press the Channel + key, if the device responds, go to step 5. If the device does not respond, press Channel + to try the next code and repeat until the device responds and go to step 5.
- 5 Press the SET key to save the code. Repeat step 1-5 to search for other device codes.

Checking the Code

- 1 Press the mode key for the device you wish to set up.
- 2 Press and hold SET until the red LED blinks twice.
- 3 Enter in 9-9-0.
- 4 Press and release the digit 1 and count the number of times the LED flashes (e.g. three flashes = 3). If the LED does not flash, this part of the code is 0. Repeat this process using digits 2-5 and record the code number:

Device Codes:

STB Code:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
TV Code:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DVD Code:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
AUX Code:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

